
Indoor Siren


1. Appearance




2. Packaging List




Indoor Siren ×1



Mounting screw ×2



Plastic expansion tube ×2



Power Adapter ×1



3M adhesive strip ×1




QSG ×1

3. Add Indoor Siren

1. Click Home Security Hub , then click "+" and select "**Add peripheral**" .
2. Plug in the cable and press the  to power up the device , the green indicator will flash and the device will show in the App.


   **Note: If the device does not show in the App and green indicator is off , please press and hold the register button for 5s to try again.*
3. Assign a room and click the "**Done**" to finish adding.



4. Testing Instruction


Signal Strength Test

Click " ⚙ "→ "**Signal Strength Test**"→ " ▶ " to check signal strength.



Volume Test

Click " ⚙ "→ "**Volume Test**"→ " ▶ " to test volume.





5. Installation Instruction


Mount on the wall by screws












Mount by 3M adhesive strip



6. Device Specifications

Parameter	Value
Model	RBAD-SI1
Alarm Buzzer	85dB/95dB/105dB
Advanced Features	Signal Strength detection，Find me
Tamper Protection	Rear
Transmission Technology	RBF Wireless Transmission
Transmission Frequency	868/915 MHz
Transmission Range(Open Space)	1900 m
Advanced Tech	AES-128 Encryption， FHSS， TDMA
Power Supply	3.7 V Lithium battery with external power plug
Operation Temperature	-10°C to 55°C (14 °F to 131 °F)
Dimension(W x H x D)	Φ80×34 mm
Weight	90 g
Application Scenario	Indoor