


Outdoor Siren

1. Appearance







2. Packaging List



Outdoor siren ×1




Mounting bracket ×1



Mounting screw ×4




QSG ×1



Plastic expansion tube ×4


3. Add Outdoor Siren

1. Click Home Security Hub , then click "+" and select "**Add peripheral**" .

2. Turn on the power switch  to power it up, the indicator will flash and the device will show in the App.

**Note: if the device does not show in the App and indicator is off, please press and hold the register button for 5s to try again.*

3. Assign a room and click the "**Done**" to finish adding.



4. Testing Instruction

Signal Strength Test

Click " ⚙ "→ "**Signal Strength Test**"→ " ▶ " to check signal strength.




Volume Test


Click " ⚙ "→ "**Volume Test**"→ " ▶ " to test volume.



5. Installation Instruction

Mount on the wall by screws





6. Device Specifications

Parameter	Value
Model	RBAD-SO1
Alarm Buzzer	85dB/95dB/105dB
Advanced Features	Signal Strength detection，Find me
Tamper Protection	Rear
LED Indicator	3
Transmission Technology	RBF Wireless Transmission
Transmission Frequency	868/915 MHz
Transmission Range(Open Space)	3100 m
Advanced Tech	AES-128 Encryption， FHSS， TDMA
Power Supply	1700 mAh Lithium battery with Solar charging， Battery Life Up to 4.2 years (standby mode)
Operation Temperature	-10°C to 55°C (14 °F to 131 °F)

Parameter	Value
Dimension(W x H x D)	290 mm x 200 mm x 58 mm
Weight	645.5 g
IP rate	IP65
Installation Method	Wall mounting
Application Scenario	Outdoor